



## TEAK RENEWER/OXALIC ACID

### DESCRIPTION

Teak Renewer/Oxalic Acid is a wooden deck brightener for removal of oil and fat and for daily cleaning on deck.

### FEATURES

- Dry acid deck cleaner
- Surface brightening of wood
- Removes stains and discoloration
- Water soluble for ease of use

### BENEFITS

Quick, efficient cleaning power

### DIRECTIONS FOR USE

1. Dissolve 5 to 10% Teak Renewer in fresh water.
2. Apply the solution on the surface with a chemical spray unit.
3. Leave for 30 to 45 minutes.
4. Wash off with fresh clean water

Code: 161161337

### TEAK RENEWER/OXALIC ACID

Teak Renewer/Oxalic Acid is used to remove wood discoloration commonly found on untreated teak, mahogany or oak decking



This information is not to be taken as a warranty or representation for which we assume legal responsibility, nor as permission, inducement or recommendation to practice any patented invention without a licence. The information is offered solely for your consideration, investigation and verification.